

Nursery Arch User Instructions

What's included:

Parts:

2x



Sides


9x



Rungs

Tools & fixings:

1 x



4mm
Allen key

18x



M6x30
Male threads

CAUTION
CHOKING HAZARD
CONTAINS SMALL PARTS
Adult supervision required




Note: Ensure dowels are pushed home in the recesses before tightening screws – a gentle tap with a small rubber mallet or the heel of your hand should help

What you will need:

- Competent adult supervision

Products covered in this guide:

Name	MPN	GTIN
Nursery Natural Arch	LPKARC-NI-NAT	5060632681621
Nursery Gretton Grey Arch	LPKARC-NI-GG	5060632681706
Nursery Pastel Rainbow Arch	LPKARC-NI-PR	5060632681768



Refer to assembly instructions overleaf

Assembly instructions:

Please refer to diagrams overleaf

1. The climbing arch should be assembled by a competent adult
2. Lay one side flat on the floor.
3. Insert a rung into each recess.
4. With all rungs vertical, place the other side on top, align and fit into each recess.
5. Ensuring correct alignment insert M6x30 bolts and finger tighten into the embedded female threads.
6. Carefully turn the arch over and repeat step 4. on the other side.
7. When all rungs are seated correctly tighten with the supplied Allen key.

Warnings:

- The recommended minimum age for the climbing arch and add-ons is 10months+
- The maximum number of users at any one time is 2
- The maximum weight per user is 50kg (∴ max 100kg)
- The climbing arch is for indoor use – it can be used outdoors with care

Do contact us if you are unsure of the assembly instructions



We recommend keeping these assembly instructions in a safe place for future reference. You can also scan the QR code for an electronic copy

Recommendations:

- The climbing arch should be positioned at least 2m from any structure that could cause an obstruction
- The climbing arch should not be installed over any hard surface
- Take care with orientation! Where there may be exposure to the sun, glare can impede climbing
- When being used as a rocker children should grab the handholds to keep little fingers off the floor and avoid being pinched underneath
- Use only manufacturer approved accessories

Maintenance:

- Regular checks should be carried out before and during use to ensure safe use of arch
- These checks include:
 - Nuts & bolts (inspect & tighten as appropriate)
 - Visual inspection for any evidence of deterioration
- Replace defective parts as per manufacturer's instructions
- A wipe over with a damp cloth after use will help maintain the climbing triangle in good order
- Failure to carry out checks & maintenance may result in products overturning or becoming hazards

Batch No.:

LIGNEUS PLAY