



4-Tier A-Frame

What's included:

Parts:




Tools & fixings:



What you will need:

- A basic level of DIY experience



Products covered in this guide:

Name	MPN	GTIN
Rustic Brown 4-Tier Frame	DS4FP-4865301455RB	5060632682369
Black 4-Tier Frame	DS4FP-4865301455BK	
Amberley Grey 4-Tier Frame	DS4FP-4865301455AG	
Kingscote Blue 4-Tier Frame	DS4FP-4865301455KB	
Tetbury Green 4-Tier Frame	DS4FP-4865301455TG	
Gretton Grey 4-Tier Frame	DS4FP-4865301455GG	

Assembly instructions:

Please refer to diagrams overleaf

1. Clarify the front and back of each leg. This is determined by the holes. The lower holes indicate the front edge.
2. Clarify the order of each box. The hole configuration widens toward the base.
3. Using 2 of the M6x30 bolts connectors and 2 M6x17 nuts fix base box to one leg. Only loosely tighten the connectors
4. Using 2 of the M6x30 bolts connectors fix top panel to the same leg
5. Now fix the other leg to the base box and top panel creating a frame
6. Now slide in the 3 tiered boxes and fasten
7. When all boxes in place tighten all connectors.

Do contact us if you are unsure of the assembly instructions

Maintenance:

These A-Frames are robustly manufactured so should be very comfortable in a busy environment. We do however recommend a wipe over with a damp cloth from time to time and also a visual check over for any defects and tighten any fastenings as appropriate.



We recommend keeping these assembly instructions in a safe place for future reference. You can also scan the QR code for an electronic copy

